

BEFORE YOU BEGIN



Scan for easy 3D instructions
Download the BILT app before you begin



USA/ États-Unis 1007261625



EASY ASSEMBLY AND OPERATION INSTRUCTIONS

22SV23277 Towering Phantom

READ AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

ASSEMBLY REQUIRES AT LEAST 2 ADULTS, 3 ADULTS ARE RECOMMENDED. PLEASE FOLLOW THE STEP BY STEP GUIDE AND ENJOY YOUR TOWERING PHANTOM!

IF ANY PART IS MISSING OR BROKEN, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT SVI CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921, EMAIL CUSTOMERSERVICE@SVIUS.COM, OR CALL HOME ACCENTS HOLIDAY CUSTOMER SERVICE FROM MON-FRI 8:00AM TO 7:00PM AND SAT 9:00 AM TO 6:00 PM EST AT 1-855-HDHOLIDAY (1-855-434-6543).


IMPORTANT TIPS:

- Ensure that the item's adapter is plugged in at the Function Control Box and in the wall.
- Ensure that the switch on the function control box is on the desired setting.
- If not functioning properly (ex: eyes & body don't light up), ensure that cables are connected to their corresponding cable as shown in the instruction sheet.
- Be sure nothing is blocking movement or caught in moving parts.
- Ensure that the floor or surface that the item sits on is flat and level.




- Ensure that the volume is not all the way down.
- Be sure nothing is blocking the sensor.
- If the item still does not work, contact SVI Customer Service from 8:30am to 5:30pm PST at 1-855-428-3921, email customerservice@svius.com, or call Home Accents Holiday Customer Service from Mon-Fri 8:00am to 7:00pm and Sat 9:00 am To 6:00 pm EST at 1-855-HDHOLIDAY (1-855-434-6543).

PARTS LIST


- A. Left Base Half x 1
 - B. Right Base Half x 1
 - C. Lower Right Support Pole x 1
 - D. Lower Left Support Pole x 1
 - E. Long Support Struts x 4
 - F. Support Struts x 2
 - G. Right Support Pole x 1
 - H. Left Support Pole x 1
 - I. Upper Right Support Pole x 1
 - J. Upper Left Support Pole x 1
 - K. Lower Torso Frame x 1
 - L. Costume x 1
 - M. Upper Torso Frame x 1
 - N. Head x 1
 - O. Right Arm x 1
 - P. Left Arm x 1
 - Q. Left Hand x 1
 - R. Right Hand x 1
 - S. Upper Cloak x 1
 - T. Base Extensions x 6
 - U. Short Support Struts x3
 - V. Stakes x 4
 - W. Support Cable x 1
 - X. Wing Nuts x 4
 - Y. Adapter * x 1
- * Power Adapter Spec
Input: 120VAC 50/60Hz
Output: 5.9V 3.0A




NOTE: Throughout the instructions, Right and Left are from the character's point of view.




NOTE: Please refer to Step 1.3 for removing and installing cotter pins.









NOTE: Please refer to Step 1.3 for removing and installing cotter pins.




NOTE: Please refer to Step 1.3 for removing and installing cotter pins.






NOTE: It is strongly recommended that 2-3 adults assist with erecting the Towering Phantom.




11.1

NOTE: (T) Base Extensions must be used for this item.




11.2

NOTE: Make sure your Towering Phantom is placed on a flat surface. Ensure that the (V) Stakes are pushed firmly into the ground through the (A,B) Base. It is advised to place weights (such as sand bags) onto the base as an added precaution. In the event that (V) Stakes cannot be used such as setting this item up indoors, on concrete, or pavement, it is strongly advised to place weights on the (A, B) Base.



11.3

YOUR TOWERING PHANTOM IS NOW FULLY ASSEMBLED. PLUG IN AND TURN ON TO LET THE FUN BEGIN!




78.25 in

15 ft

OFF • TRY ME / ARRÊT • ESSAIE-MOI

ON / MARCHÉ

TIMER / MINUTEUR



NOTE: Make sure the waterproof cap is covering the Try Me receiver at all times when not in use.

WARNING:

- Lay product down before a storm or strong winds.
- Don't climb or pull on product.
- Don't add to or modify product.
- Assemble and place the product on level surfaces only.
- Don't push or tilt product.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by manufacturer.
2. Please assemble item according to instructions. Connect all wires according to matching color.
3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

CARE AND STORAGE INSTRUCTIONS

When not in use, store this product in its original packing. Keep away from heat and moisture.

OPERATION INSTRUCTIONS:

The Towering Phantom is powered by an adapter. Plug the power adapter into a standard power outlet. To turn on the Towering Phantom, press the button on the Adapter Receiver. Press the button again to switch to the Timer setting. Press the same button a third time to turn the item Off.

The item is activated by pressing the button on the Adapter Receiver and has the following settings:

Off • Try me	This setting will deactivate the color changing lights of the item. This mode also allows the item to be activated if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for 20 seconds with each Try Me activation.
On	This setting will activate the color changing lights of the item.
Timer	This setting will operate same as "ON" with 6HR on/18HR off period.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.
CAN ICES-003(B)/NMB-003(B)



WE SUGGEST AT LEAST TWO ADULTS FOR ASSEMBLY



NO MOVING AFTER FULLY ASSEMBLED



LEVEL AREA ONLY



USE ADAPTOR



CONTACT US
IF EYES, MOUTH,
LIGHTS DON'T WORK



DO NOT PUSH OR TILT



DO NOT CLIMB OR PULL ON



DO NOT ADD TO OR MODIFY



DO NOT DISPLAY DURING STRONG WINDS



CONTACT US
1-855-434-6543

© Seasonal Visions International
Emeryville, CA 94608
Tel: 1-855-428-3921
All Rights Reserved
MADE IN CHINA