USE AND CARE GUIDE

8.5FT GIANT-SIZED LED UNDEAD HORSE



USA Item 1013315455
Model 25SV25060

ASSEMBLY REQUIRES AT LEAST 2 ADULTS. PLEASE FOLLOW THE STEP BY STEP GUIDE AND ENJOY YOUR 8.5FT GIANT-SIZED LED UNDEAD HORSE!

Questions, problems, missing parts? Before returning to the store, Please have a copy of your receipt ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM

PARTS LIST

A. Base x 1
B. Left Hind Leg x 1
C. Right Hind Leg x 1
D. Pelvis x 1
E. Spine with Control Box x 1
F. Chest x 1
G. Neck x 1
H. Head x 1
I . Reins x 1
J. Left Front Leg x 1
K. Right Front Leg x 1
L. Small Parts Bag x 1
M. Tail x 1
N. Stakes x 4
O. Adapter x 1

Power Adapter * Spec
Input: 120V~50/60Hz
Output: 5.9V ⎓ 2.0A
Wattage: 11.8W



NOTE: Throughout the instructions, Right and Left are relative to the character.
Hex wrench included for assembly.



1.1



1.2



2.1



2.2


F
E

F
Screw
M6*31mm
E
Cable pairs are color-coded to ensure proper color-matching connections.
NOTE: When connecting cables, ensure that the arrow indicators on each cable end are lined up with and pointing at each other. There is also a groove and a rod like protrusion by these arrows that fit into each other. Then firmly press the cables together. Rotate the cable cap clockwise onto the threading of the corresponding cable until firmly in place.
3.1


NOTE: Lean the assembly onto the box the horse came in as shown.
Outer Box
3.2


G
F
4.1
Screw
M6*31mm
G
F
4.2


Locking Pin
Click
Means It's Locked
H
G
4.3


G
I
5.1
H
I
5.2
5.3


6.1



7.1



7.2



8.1



8.2

NOTE: The 8.5FT GIANT-SIZED LED UNDEAD HORSE has 3 different function settings (LIGHTS ONLY, TIMER*SENSOR and OFF*STEP PAD). Settings can be controlled at the Control Panel located on the back side of the Spine with Control Box (E).

OPERATION INSTRUCTIONS - CONTROL BOX:

Plug the power adapter into a standard power outlet. Locate the push button at the back of the Spine with Control Box (E).

Button	Function Description
1 LIGHTS ONLY / ÉCLAIRAGE UNIQUEMENT / SÓLO LUCES	In this mode, the lights of the item will stay on indefinitely unless the switch mode is changed.
2 TIMER • SENSOR / MINUTEUR • DÉTECTEUR / TEMPORIZADOR • SENSOR	Set the switch to "TIMER * SENSOR" to activate the TIMER * SENSOR mode. This will activate SENSOR mode for 6 hours followed by a deactivated period of 18 hours. This cycle will continue indefinitely unless the setting is changed. During the 6-hour active period, the lights will always stay on, but the animation and sound can be triggered by the Infra-red (IR) sensor. If the Infra-red (IR) sensor is activated, the 8.5FT GIANT-SIZED LED UNDEAD HORSE will activate for one activity cycle (animation). The infra-red (IR) sensor has a range of up to 4 m/13 ft and will activate when someone comes within an 80-degree angle from left to right as well as from above or below.
3 OFF • STEP PAD / ARRÊT • TAPIS ÉLECTRONIQUE / APAGAR • ALMOHADILLA DE PASO	This switch mode allows the item to be activated only if triggered by using a Step Pad or Try Me Button (Not Included). The lights, sound, and animation of the item will operate for one activity cycle with each Step Pad or Try Me activation. Otherwise,the item will stay off.



WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.
1. Please use the adapter supplied by manufacturer.
2. Please assemble item according to instructions. Connect all wires according to matching color.
3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.
Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

☐ Lay product down before a storm or strong winds.
☐ Don't climb or pull on product.
☐ Do not add to or modify unless accessory is designed for product
☐ Assemble and place the product on level surfaces only.
☐ Don't push or tilt product.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

☐ Reorient or relocate the receiving antenna.
☐ Increase the separation between the equipment and receiver.
☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
☐ Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES (B) / NMB (B)

FAQ:

Why are the eyes of my 8.5FT GIANT-SIZED LED UNDEAD HORSE not working or do not light up?

• Check and ensure that all cables are connected to their corresponding cable as shown in the instruction sheet (See steps 3.2 and 4.3)

My item does not activate or turn ON?

• Check that the adapter is properly connected with the threaded cap fully tightened to your 8.5FT GIANT-SIZED LED UNDEAD HORSE and is plugged into a live outlet. (See page 3)
• Check and ensure that there is power to your 8.5FT GIANT-SIZED LED UNDEAD HORSE by checking for the red indicator light on the control panel. If there is power, a red indicator light will light up on the control box. If the red light indicator is set to "OFF", please change it to "ON" or "TIMER."

If all the information above does not solve your issue, please contact our SVI customer service experience team email (customerservice@svius.com) or call Home Accents Holiday Customer Service Hotline 1-855-HD-HOLIDAY (1-855-434-8543).

Questions, problems, missing parts? Before returning to the store, Please have a copy of your receipt ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM